

2015+ Ford F-150 Tailgate Handle Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-247-3974
 Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)
 Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	Qty
Lift Handle	3
Electric Handle	1

Tools Required:

- Rubbing Alcohol
- Clean Towel

Handle Installation

1. Clean and dry the vehicle thoroughly.
2. The vehicle surface temperature must be a minimum of 15°C (60°F).
3. Apply rubbing alcohol to the clean towel and wipe down the entire boxed area shown in Figure 1 on the tailgate. This will ensure proper adhesion to the vehicle. (Electric handle shown)



4. If your vehicle has an Electric handle, your kit will have a 1-piece tailgate handle cover. If your vehicle has a Manual lift handle (Figure 4), your kit will come with a tailgate handle cover and a separate lift handle cover. As shown in Figure 2, remove the 3M tape from back of the tailgate handle cover. (Electric handle cover shown)



5. Align the tailgate handle cover over the existing plastic handle surround. **IMPORTANT: Do not to allow the adhesive surface of the panels to touch the vehicle prior to being in the correct location.** Ensure the camera hole in the handle cover is sitting flat around the camera. If there is a gap, the handle cover is not sitting properly and will not properly adhere. When aligned, press and hold in position for 30 seconds to ensure proper adhesion. See Figure 3 for proper alignment. (Electric handle shown)



6. If your vehicle has a Manual lift handle, install the outer bezel first (see Steps 4 & 5). Check the clearance of the lift handle cover (Figure 4) before removing the 3M tape. Once verified, remove the 3M tape. Align the lift handle cover over the existing plastic lift handle. **IMPORTANT: Do not to allow the adhesive surface of the panels to touch the vehicle prior to being in the correct location.** When aligned, press and hold in position for 30 seconds to ensure proper adhesion.
7. Determine if you have a backup camera. If the camera is present, discard the camera cover. If the camera is not present, install the lift handle cover and the camera cover shown in Figure 4.

