



Steeda Pro-Flow Blow-Off Valve Adapter

Installation Instructions for Part: 555-3215



1. **Locate the factory re-circulation/by-pass valve.** (See below for more details on the location of this valve in your vehicle.)
2. **Unplug the factory re-circulation/by-pass valve and remove it.**
3. **Place the Steeda Pro-Flow Blow-Off Valve Adapter in between the factory re-circulation/by-pass valve.**
4. **Install the o-rings.** (NOTE: The use of grease may be helpful to retain o-rings.)
5. **Bolt in place using the bolts provided in the kit.**
6. **Reconnect and enjoy!**

For 1.6L Fusion:
Remove the passenger side wheel and locate the re-circulation/by-pass valve.



For 1.5L Fusion and 2.7L Fusion Sport:
Open the hood and locate the re-circulation/by-pass valve near the brake master cylinder.



For 2.3L Mustang Ecoboost:
Open the hood and locate the re-circulation/by-pass valve under the coolant reservoir.

