



AMERICAN CAR CRAFT INSTRUCTIONS

Ford Raptor Rear Tag Frame PART #772017



Parts Included:

- 1-Chrome/Stainless/Carbon Fiber Tag Frame
- 2-6MM Bolts
- 2-124NC 10mm Chrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

Thank you and enjoy your purchase!

**If any questions occur during installation please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**