

8F1600 - Ford Coolant Overflow Cover F150 Raptor

8F1600 - Ford Coolant Overflow Cover F150 Raptor

Ford Raptor 2017 - 2019



Congratulations on your purchase of the COBB Tuning Overflow Cover! The following instructions will assist you through the installation process. Please read them BEFORE beginning the install to familiarize yourself with the steps and tools needed. If you feel you cannot properly perform this installation, we HIGHLY recommend you take the vehicle to a qualified and experienced automotive technician.

Table of Contents

- Table of Contents
 - Parts List
 - Tools Needed
 - Sockets
 - Hand Tools
 - Coolant Cover Installation
 - Links
-

Parts List

- COBB Coolant Overflow Cover

Tools Needed

Sockets

3/8"

- 3/8" ratchet
- 3/8" 12" extension
- 3/8" 6" extension
- 3/8" 10mm socket

Hand Tools

- Needlenose pliers
-

Coolant Cover Installation

1. Cut the strip of foam tape to fit across the top piece lining up with the small cross piece in the cutout.



2. If necessary rotate the clamp around in order to get it as low as possible. Make sure not to rotate the hose itself, as that can cause undue stress on the line.





3. Loosen the two 10mm bolts slightly then slip the cutouts in the bottom edge of the coolant cover between the vehicle and the coolant bottle.



4. Line the cutout up with the lid so it looks even.



5. Stick your socket through the cutout and tighten down the coolant bottle again.





6. You're all done! Go out and enjoy!



Links

Error rendering macro 'excerpt-include' : You can only link to a page or blog post.