



## CJR002 S550 JACKING RAILS

### Tools required:

1. Ramps or jack and jack stands
2. Ratchet Handle or Impact Gun
3. 15mm socket

### Installation:

1. Place vehicle on ramps or lift vehicle and secure on jack stands
2. Remove all eight (8) **15mm bolts** from the frame rail as shown in **IMAGE 1 and 2**.
3. Install jacking rails using the same factory **15mm bolts** as shown in the last image.
4. **Tighten to 41 ft/lbs.**



**NOTE: Drivers side rail is longer than passenger side and the closely spaced holes go toward the front of the vehicle on both rails.**



## **CJR002 S550 JACKING RAILS**

*continued*



**WWW.BMRSUSPENSION.COM**

*This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.*