

**CAMBER KIT**

---

*This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.*

---

**Plan Ahead - Read All Instructions BEFORE installing**

1. Remove the tire and wheel assembly.
2. Remove the strut flange from the knuckle assembly and, using #85130 Rotary File Set, elongate the lower strut flange holes (equally on both sides of the original hole if possible) just enough so that the ears on the plate fit tight in the elongated hole.

**NOTE: Some vehicles may already have the lower strut hole elongated.**

3. Re-install the knuckle to the strut flange with the top bolt.
4. Install the ears of the cam plate into the elongated hole and the cam bolt through the cam plate, strut flange and knuckle assembly.
5. Tighten nuts snugly but loose enough to allow adjustment.
6. Using a wrench, adjust camber to the desired settings.
7. While holding the bolt head to eliminate cam rotation, torque the strut flange nuts to manufacturers' specification.

***Always check for proper clearance between suspension components and other components of the vehicle.***



**Specialty  
Products  
Company®**

4045 Specialty Pl. • Longmont, CO 80504 • (303) 772-2103  
www.specprod.com • www.spcperformance.com  
Email: info@specprod.com

Printed in U.S.A.

**Toll Free Technical Hot Line: 1-800-525-6505**