



Mount the top edge of the paper in the middle of the body line on the fender



**** Be sure to use the supplied alcohol pads to prep **
surface before installation of emblems**



**Use a sharp razor on a flat surface
Cut out inside of black box to make template**



Mount this edge with the door body line

8.5 - inches wide

Driver Side Template

To install on passenger side just use the opposite side of template and line up arrows same as pictured.

Carefully apply inserts and rear adhesive to emblem indoors



11 - inches long

Center on bodyline ↓

↑ Place the top edge of the paper in the middle of the body line on the fender ↑

** Be sure to use the supplied alcohol pads to prep **
surface before installation of emblems

Use a sharp razor on a flat surface
Cut out inside of black box to make template

2.3T

Driver Side Template
To install on passenger side just
use the opposite side of template
and line up arrows same as pic-
tured.

Carefully apply inserts and
rear adhesive to emblem
indoors

↑ Round the edge with the door body line ↓

11 - inches long

**Line up with
bodyline**

