



Steeda Interior Hood Latch Lever

Installation Instructions For Part: 555-1248, 555-1248-BL, 555-1248-RED



Tools required

1. Thin wall ¼" drive 10mm socket or small flathead screwdriver.

Disassembly:

1. Remove the small plastic cover on the factory hood latch lever.



Figure 2



Figure 1

2. Using a 10mm socket depress the pins holding the factory lever in place and wiggle unit until it comes loose. If using a screwdriver depress one ear at a time until you can wiggle the factory lever free.



Figure 3



Figure 4

3. Line up the Steeda levers' two cutouts with the steps inside the factory panel and press the Steeda lever into place, applying pressure until you hear the detent tabs click.



Figure 5

Your assembly is complete!