

87-04 Mustang Billet Window / Door / Mirror Kit Installation

Window / Door Lock Switches Installation:

To remove the existing factory window and door lock switches:

1. While pressing each window / door switch down, insert a small flat headed screw driver under the switch button.
2. Gently pry up on the switch taking care not to mark the door panel. Each switch should simply “pop” off.



3. Replace each factory window / door lock switch with its billet replacement.



Directional Mirror / Mirror Lock Switches Installation:

To remove the existing factory window and door lock switches:

1. While holding the directional mirror switch to the left, insert a small flat headed screwdriver under the button.
2. Gently pry up on the switch taking care not to mark the door panel. The switch should simply “pop” off. Use the same procedure for removing the Left / Right Selector.



3. Place the new billet mirror switch on the mounting post and gently press down until the switches are fully seated.



Convertible Switch Kits:

The convertible versions of our Switch Kits come with 2 additional Window buttons, and an additional Lock Button. Follow the same removal and installation instructions for these buttons.