

## 79-04 Mustang Billet Trick Stick Installation

1. Remove the factory shifter knob by simply unscrewing it counter-clockwise.



2. Remove the factory shifter boot and trim by gently lifting it up. It will simply “pop” off.



3. Remove the factory shifter handle by removing the two shifter handle bolts.



4. Install the new Billet Trick Stick using the supplied bolts. Torque to factory specifications. Then reinstall the factory shifter boot, trim and knob.

