



California Pony Cars
NXT Generation Engine Plenum Extension Throttle Body Cover
PN ENG-059-599 / ENG-000-430/ENG-010-348
Installation Instructions

Important Please read entire instructions before attempting to install this product. This will prevent any missteps that could complicate the process or cause damage to yourself or your Mustang.

****Note**** The Plenum Extension Throttle Body Cover is a close color match to the factory OEM plenum cover, but may not always be 100%. There may be a slight variation in color between the OEM Plenum Cover and the Throttle Body Cover

Three simple steps to install the Plenum Extension Throttle Body Cover.

Tools required:

- Ratchet
- Extension
- 5/16 Socket

- **Step one:**

Loosen the nuts from the front engine plenum studs, **but do not remove** the nuts completely.

- **Step two:**

Carefully install the Throttle Body Cover on the front engine plenum studs, make sure it's set correctly.

- **Step three:**

With ratchet, extension and a 5/16 socket **gently** tighten the nuts.
Do not over tighten.

