

STEEDA®
Steeda S550 Mustang
Installation Instructions For Part: 555-5533



Tools required:

1. Jack
2. Jack Stands
3. File or chisel
4. 22mm wrench
5. 22mm socket

Installation:

1. Place your car securely on jack stands or a lift.
2. If there is any metal slag left over on the subframe in the circled holes below, you will need to remove it. A file or a chisel will work well for this.
3. Completing one side at a time, insert the provided spacer rearward most hole in the subframe.
4. Position the brace into position so that the spacer cannot fall out of the subframe.
5. Install the provided bolt from below the stamping and secure it with the provided nut.
6. Using a 22mm wrench and a 22mm socket, tighten the bolt snugly and then continue the installation repeating steps 3-6 on the other side of the vehicle.
7. Break off the installation wire on the spacers.
8. Remove your vehicle from your jack stands and enjoy!

