

DV8 Offroad Light Bar Mount

UNIVERSAL

LBUN-01



TOOLS REQUIRED

- #3 & #4 Allen Head
- 10mm Socket or Wrench
- Zip Ties (Not Included)

SKILL LEVEL

- Novice/Intermediate
 - 1 person
- Beginner skill required. Simple wiring required.

TIME REQUIRED

- Approximately 30 Minutes
- Time to install this should take about 30 Minutes

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



INSTALLATION MANUAL

STEP 1

INSTALLATION OF LIGHT BAR

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from.

Hardware Included:

- (4) M6x20mm
- (4) M6 Lock Nuts
- (8) M6 Flat Washers



STEP 2

Begin by taking your 13" Light and installing it to the light bar bracket. Shown in the images is the DV8 Elite 13" bar. Using the M8 bolts and flat washers (provided with light), install the light into the bracket.



STEP 3

Secure wiring using welded zip tie tabs along the side of the bracket.



INSTALLATION MANUAL

STEP 4

Install the die cut foam on the bottom of the bracket to prevent damage to the coating on the bumper and light bracket.



STEP 5

Once light is installed, remove the screen from the top of your compatible DV8 Bumper using your #3 allen head and 10mm socket/wrench.



STEP 6

Install the light bracket onto the bumper reusing the hardware from the screens.

Note: You can reinstall the screens and run the wire with the screen in place if you choose.



INSTALLATION **MANUAL**

STEP 7

Secure bracket and wire light to power.

**LBUN-01 shown installed on a 2021 Bronco (MTO Series Bumper)*

You're ready to run your new DV8 universal light bar mount.

