

2015 Mustang Shift Knob Installation

2015 Mustang Shift Knob Installation Instructions



Please read the installation manual before installing our 2015 Shift Knob and verify that all items are present. If you are missing hardware or have any questions, please contact us at 1-800-888-6473.

TABLE OF CONTENTS:

Packing List for 2015 Mustang Shift Knob Kit..... 1

Equipment and Supplies Required..... 2

Safety Precautions..... 2

Original Shift Knob Removal..... 2

Shift Knob Installation..... 3

PACKING LIST FOR 2015 MUSTANG SHIFT KNOB KITS

Description	Quantity
Shift Ball	1
Threadlock (Loctite® 243)	1
Instructions	1

2015 Mustang Shift Knob Installation

EQUIPMENT AND SUPPLIES REQUIRED

Brake Cleaner (or another film-less surface preparation)

STOP!

SAFETY PRECAUTIONS

CAREFULLY READ THE IMPORTANT SAFETY PRECAUTIONS AND WARNINGS BEFORE PROCEEDING WITH THE INSTALLATION!

Appropriate disassembly, assembly methods and procedures are essential to ensure the personal safety of the individual performing the kit installation. Improper installation due to the failure to correctly follow these instructions could cause personal injury or death. Read each step of the installation manual carefully before starting the installation.

- Always apply the parking brake when working on a vehicle.
- Block the front and rear tire surface to prevent unexpected vehicle movement.
- If working with a lift, always consult vehicle manual for correct lifting specifications.
 - Use chemicals and cleaners in well-ventilated areas.
- Do not wear loose clothing or jewelry that can get caught in rotating parts or scratch surface finishes.

ORIGINAL SHIFT KNOB REMOVAL

1. Place the shift knob in reverse. Grip the stock shift knob tightly and turn counterclockwise to unscrew the knob from the threads of the shifter lever. If necessary, Use a rubber mat to improve grip on the shift knob to prevent your hands from slipping.
2. Inspect the threads on the shift-lever for debris and remove any if found. Clean the oils off the threads using brake cleaner or equivalent cleaning agent and allow the agent to dry/evaporate.



2015 Mustang Shift Knob Installation

SHIFT KNOB INSTALLATION

1. Apply blue threadlocker to the shift-lever.
2. Screw the shift knob on the shift-lever. Exercise caution when lining up the threads on the shift knob to the shift-lever as they can easily be cross threaded if misaligned. Turn the knob clockwise to secure the knob.
4. Take the shift knob out of reverse. Once out of reverse, lift the reverse lockout and shift back into reverse. If you cannot shift into reverse smoothly, back the knob out by turning it counterclockwise until there is enough clearance for the reverse lockout to function properly. Once in its final position, allow the threadlocker on the threads to cure overnight without disturbance.

Do not over tighten! Damage to the shift knob may occur if over tightened.



Congratulations!! You have completed the installation of the 2015 Ford Mustang shift knob.

3. Screw the shift knob down about 6 rotations until the bottom of the knob sits close to the lockout. continue to turn clockwise until the shift pattern on the top of the knob rests in the desired position.

