



Driven Beyond Perfection

# Billet Accelerator Pedal

## INSTALLATION INSTRUCTIONS

For part #: C5ZZ-9732-DBL

**APPLICATIONS: 1965 - 1970 Mustang**

*Thank you for purchasing the Scott Drake Billet Accelerator Pedal!*

### READ BEFORE INSTALLING

1. Remove screw located underneath stock pedal assembly, unhook pedal spring from pedal pivot arm and remove pedal. Note how spring is situated behind pedal.
2. Install Billet Accelerator Pedal on pedal pivot arm. Make sure spring in the same position as it was in the stock assembly. Refer to the shop manual if you have difficulties with locating the spring assembly. Install and tighten new screw using 6mm hex head wrench.  
**Note: Do not use original screw with Billet Pedal.**
3. Check assembly for smooth movement.