

SCOTT



Driven Beyond Perfection

Billet Pedal Cover

INSTALLATION INSTRUCTIONS

For part #: C5ZZ-2457-FBL, C60Z-2457-ABL,
C5ZZ-2457-GBL, C5ZZ-7A624-BBL

APPLICATIONS: 1965 - 1970 Mustang

Thank you for purchasing one of our Scott Drake Billet Pedal Covers!

READ BEFORE INSTALLING

1. Remove rubber pedal pad from pedal by grasping edges and pulling upwards. This may require a bit of effort depending on pad condition and adhesive used to secure existing pad.
2. Clean metal pedal surface with soap and water or stronger cleaning product if pedal surface is especially dirty.
3. Remove billet pedal cover from package and place over pedal. Use marker to transfer hole location from pedal cover to pedal surface. It may be advantageous to use a marker color other than black (silver, etc.) to mark the holes.
4. Remove pedal cover and center punch the marks you made through the pedal cover mounting holes. A spring loaded center punch works well for this operation.
5. Drill through the pedals, in the center punched locations using a 5mm or 3/16 drill bit. Deburr holes. Install covers using the supplied screws, washers and nylon locking nuts. You will need a 2.5mm hex wrench and a 7mm wrench or socket.