

# Part # 4447

## 2015-Present Ford Mustang Quarter Window Louver

**Notice: Install new parts according to these instructions!**  
**Altered and/or painted parts are Non-Refundable!**

**Step 1**

These louvers install directly to the glass surface. The glass surface must be clean of ALL dirt and any oily residue. Use rubbing alcohol and a clean rag or towel to clean the glass surface.

**NO  
IMAGE**

**Step 2**

Apply the 2 sided tape to the back side of the louver as shown in fig.A. After the 2-sided tape is installed remove all of the backing, line up the louver with the rear corner of the glass (do not allow any other portions of the tape to touch the glass). Then line up the louver with the top trim while still holding the lower portion away from the glass. Lastly, attach the bottom and front of the louver to the glass.



**Fig.A**

**Step 3**

Firmly press on the louver in the areas where the 2 sided tape is contacting the glass.

**IMPORTANT**

Allow the tape to adhere for 24 hours before driving the car. Failure to do so will result in tape failure.

**NO  
IMAGE**

PART # 4447		
QTY	DESCRIPTION	HARDWARE #
VHB134	1/4" VHB 5952 TAPE	TAPE/DS/.25



TOOLS & MATERIALS NEEDED	
DESCRIPTION	
	RUBBING ALCOHOL
	LINT FREE COTTON RAG OR PAPER TOWEL