



**2015 Outlaw High Mount Spoiler (Coupe ONLY)  
CDC# 1511-7012-01**

**TEST FIT BEFORE PAINTING!!!**

**NOTE:** This product is Injection Molded TPO. We recommend taking to an Automotive Paint Facility to be painted however, it may be installed as is. Standard Fascia paint processes should be used.



**Note: READ instructions before starting installation!!!**

**Components:**

- 1 - Outlaw High Mount Spoiler
- 1 - Alcohol Pack
- 1 -GAP-1 Adhesion Promoter Pack

**CDC Part#**

- 1511-2310-01
- 950006
- 950008

**Tools Required:**

- Glass Cleaner
- Clean Rag
- Masking Tape

**Installation Instructions**

1. Clean the rear glass with Glass Cleaner and a clean rag.
2. Clean the glass with the supplied **Alcohol Pack**, and allow to dry.
3. Place the **High Mount Spoiler** in location and apply some masking tape as reference as shown in pic.



4. Remove High Mount Spoiler from car and apply the supplied **GAP-1** Adhesion Promoter. Allow time to thoroughly dry.



5. Apply **GAP-1** to the top of the 3<sup>rd</sup> Brake Light and allow to dry.



6. Install the **High Mount Spoiler**. **HINT:** The help of a friend will make this step much easier. While one person holds one side of the High Mount Spoiler down on the glass, the other person lifts their side and removes the red backing from the tape. After the backing is removed, press into position and repeat on the other side. **Press firmly to activate adhesive of 3M Acrylic Foam Tape.**



Thank you for choosing Classic Design Concepts for your restyling needs. If you have any questions or concerns regarding installation please contact [Tech@CDCdetroit.com](mailto:Tech@CDCdetroit.com) or call 866-624-7997