



757-842-6497
WWW.JLOSC.COM

**J&L 3.0 Oil Separator, Passenger Side
(2011-14 Mustang GT, 2011-14 GT w/ Front feed Whipple Supercharger – Remote Mount)
#3041P**

Installation Instructions

Check out the installation video on our website www.JLosc.com Search: 3041P and click videos

Please review complete instructions prior to installing.

	<p>Verify you have all the following parts included in the kit: (1) J&L Oil Separator/hose assembly (1) J&L Mounting bracket, (2) Fine thread machine screws, (1) Grounding stud, (1) M6 nut</p>
1	<p>Remove the strut bar if equipped, engine cover and the stock PCV line from the valve cover to manifold.</p>
2	<p>Use supplied grounding stud and nut to attach the mounting bracket shown here: IMPORTANT! Ground strap must go between J&L stud and body to still make the ground. Like shown below.</p> <div data-bbox="214 800 959 1356" data-label="Image"></div> <div data-bbox="1029 846 1523 1073" data-label="Text"> <p><u>NUT</u> <u>BRACKET</u> <u>GROUNDING STUD</u> <u>GROUND STRAP</u></p> </div>
3	<p>Use the M4x10 screws to attach J&L Separator to the J&L Bracket.</p> <div data-bbox="170 1423 971 2020" data-label="Image"></div>

Route hoses to connect and you are done!



4

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thank you for your business. If you have any questions, please e-mail info@JLosc.com or call 757-842-6497. Our hours are Monday-Friday, 8:00am – 5:00pm Eastern Time.

J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.JLosc.com/warranty

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLosc.com for complete return policy.

Disclaimer: J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.