




757-842-6497
WWW.JLOSC.COM


Installation Instructions
J&L Oil Separator, Passenger side (1999-2004 Cobra, 2003-2004 MACH I)
#3018P

Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (1) J&L Oil Separator with fittings, (1) Mounting bracket, (2) Hoses, (2) M4x10 screws and (1) ½" threaded 90° fitting
2	Gather all of the following tools needed for the installation: Phillips screwdriver, 10mm wrench or socket/ratchet
3	Remove the 10mm nut/bolt holding the AC line to the engine shown here: 
4	Use previous nut/bolt to mount the J&L bracket
5	Use the supplied screws to mount the J&L Separator to the J&L bracket
6	Thread 90° fitting into the grommet in the valve cover

7

Use oil on the fittings and connect the hoses as shown:



To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thank you for your business. If you have any questions, please e-mail info@JLosc.com or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 5:00pm Eastern Time.

J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.JLosc.com/warranty

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLosc.com for complete return policy.

Disclaimer: J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.