



VAREX

Varex Key Fob Installation Instructions

XFORCE RECOMMENDS AN AUTHORISED PROFESSIONAL TO INSTALL ALL PRODUCTS

WARNING: When working on any vehicle exercise extreme caution. Please allow the vehicles exhaust system to be cool enough to touch before removal. Failing to do so may result in severe burns. If working without a hoist refer to the vehicles manual to check correct lifting specifications. Always wear safety glasses, protective gloves and ensure your working in a safe area. Serious injury or death can occur if the correct safety measures are not followed.

Attention: Please read the instructions carefully. XFORCE will only warrant manufacturing faults. This does not extend to damage or breakage due to incorrect fitment.




What's inside the box

- 1 Varex Control Module
- 2 Main Wiring Harness (VK1 or VK2)
- 3 Key Fobs




Varex
Key Fob Module

Key Fobs



12 V Socket Plug
For Accessories Power Only




Single Muffler Harness


VK01

Varex
Key Fob Module

Key Fobs



12 V Socket Plug
For Accessories Power Only



VK02

Twin Muffler Harness



Step 1

Find a rubber grommet to allow access from the boot area to the underside of the car near the Varex Mufflers. Once located feed the black 2 pin plug through the boot area to the underside of the car and connect to the muffler VK1 (Ref P3) or mufflers VK2 (Ref P4).





Step 2


Feed the wiring through the boot towards the back seat, then run the wire into the cabin and under the back seat, towards the plastic cover between the carpet and the doors.

Put your fingers under the cover (pic 1) then push the wiring up under the cover (pic 2).


Do this all the way to the front of the cabin and feed the wire behind the kick panel Pic 3 (plastic cover near where your feet would be in the front of the car).



Pic 1



Pic 2



Pic 3



Step 3

Plug the Key Fob box into the white 4 pin plug and the (pic 4)

Remove the panel under the dash (pic 5) and place the wiring and box on the panel (pic 6), run the wire (with the 12V Socket Plug) towards the 12V Socket.



Pic 4



Pic 5



Pic 6



Step 4


Feed the wiring under the plastic between the centre console and the carpet moving it towards the centre of the car (pic 7 towards the seats) as far as is needed to reach the power socket (pic 8).

Turn the car on and test the system using the remote
Button A will close the Varex and button B will open the Varex

Now enjoy the volume controllability of your new Varex System



Pic 7



Pic 8